

FARMTRAC
50/55/60

This document provided free of charge by
www.redbayfarm.com

TRACTOR
REPAIR MANUAL

LONG AGRIBUSINESS

Box 1139 (111 Fairview St.)

Tarboro, N.C. 27886

Tel. (252) 823-4151

E-mail: LONG AM @ AOL.COM.

FOREWORD

This manual provides information for the proper Servicing, Maintenance and Repair of the Farmtrac-50/55 and Farmtrac-60 tractors. It is intended for use as a reference book by all the trained Servicemen engaged in servicing, maintenance and repairs at all authorised outlets, and, however does not substitute the necessity of getting the service personnel trained, through the various courses conducted every year.

The manual is divided into several Sections which contain information on general operation, inspection and repair procedures and specifications of the various systems individually. For easy reference, each section has been given separate alphabetical code letter as shown in the index.

All servicing, maintenance and repair operations, take into account the special service tools which have been illustrated wherever possible and, where trouble shooting procedures are thought to be of assistance, these have also been incorporated in the appropriate chapter.

The page and figure number are serially numbered throughout each Section. This will permit any revised pages to be readily included in the respective Section at any later date as and when these would be issued.

The material contained in this manual was correct at the time the manual was approved for printing, and, we reserve the right to discontinue or change specifications or design of any model without notice and without incurring obligation whatsoever.

LONG AGRIBUSINESS

Box 1139 (111 Fairview St.)
Tarboro, N.C. 27886
Tel. (252) 823-4151
E-mail: LONG AM @ AOL.COM.

INDEX TO SECTION

This document provided free of charge by
www.redbayfarm.com

SI. No.	SECTION	CODE
1.	ENGINE SYSTEM	A
2.	COOLING SYSTEM	B
3.	FUEL SYSTEM	C
4.	ELECTRICAL SYSTEM	D
5.	SINGLE CLUTCH	E
6.	DOUBLE CLUTCH	F
7.	TRANSMISSION SYSTEM	G
8.	POWER TAKE OFF	H
9.	REAR AXLE AND BRAKES	I
10.	HYDRAULIC SYSTEM	J
11.	STEERING SYSTEM (RE-CIRCULATING BALL TYPE)	K
12.	HYDROSTATIC STEERING	L
13.	FRONT AXLE (MECHANICAL STEERING)	M
14.	FRONT AXLE (HYDROSTATIC STEERING)	N
15.	FRONT AND REAR WHEELS	O
16.	SEPARATING THE TRACTOR	P
17.	REMOTE CONTROL VALVES	Q